



**Thermal
Fire
Corrosion**

Call us for more information at 604-576-2212

NCFR102 - Application Instructions

Application Instructions for NCFR102

Brush, roll or spray with airless spray. Avoid WFT greater than 8 mils per coat.

Surface preparation: Surface should be prepped and/or primed.

Cure times:

Dry to recoat.....30 min.
Dry to touch.....1 hour
Dry to handle..... 4 hours
Thorough cure..... 1 week

Spread rate

16 mils WFT at 2 coats cross hatched of 8 mils WFT each.
8 mils DFT.
Coverage: 100 square feet per gallon.