



**Thermal  
Fire  
Corrosion**

*Call us for more information at 604-576-2212*

## **NCFR102 - Application Instructions**

### **Application Instructions for NCFR102**

Brush, roll or spray with airless spray. Avoid WFT greater than 8 mils per coat.

Surface preparation: Surface should be prepped and/or primed.

#### **Cure times:**

Dry to recoat.....30 min.  
Dry to touch.....1 hour  
Dry to handle..... 4 hours  
Thorough cure..... 1 week

#### **Spread rate**

16 mils WFT at 2 coats cross hatched of 8 mils WFT each.  
8 mils DFT.  
Coverage: 100 square feet per gallon.